

■ LUGGAGE BOX OPENER KIT HONDA NC700S, NC700X

If you want to open a luggage box in NC700X NC700S, Stop the engine, If you do not replace the ignition key into the keyhole open for boxes, You can not open the luggage box lid.
Do not replace the ignition key, State was placed in the main switch, Key ON, Simply press the switch, You can open the luggage box. Can also be opened with the ignition key. You can be installed without the need for wiring processing.



05-09-0026



05-09-0027



Name	LUGGAGE BOX OPENER KIT
Applicable model	NC700S(RC61-1000001~)
Item number	05-09-0026

Name	LUGGAGE BOX OPENER KIT
Applicable model	NC700X(RC63-1000001~)
Item number	05-09-0027