# Air filter Instruction Manual

Product number	Mounting diameter	Shape	Carburetor type
03-01-100	42mm	Round taper	MIKUNI VM24/26
03-01-101	46mm	Round taper	KEIHIN PE20/22/24
03-01-103	49mm	Round taper	KEIHIN PE28 PWK28
03-01-104	32mm	Round taper	KEIHIN PC18/20
03-01-1132	39mm	Round taper	MIKUNI VM22 KEIHIN PD22 PB18
03-01-102	42mm	Round straight	MIKUNI VM24/26
03-01-1133	39mm	Round straight	MIKUNI VM22 KEIHIN PD22 PB18

Thank you very much for purchasing our products. Thank you so you will comply with the following matters at the time of use. Before installation, please check your always kit contents

If there is a point of notice event, Please contact us the dealer of purchase.

### O Illustrations and descriptions such as photographs may be different from the present parts, please understand.

- The use of ignoring the instructions that are written in the instruction manual, if an accident or damage has occurred, we can not assume any responsibility for compensation.
- This product installation and use, when a problem occurs to after market goods, guarantee other than this product, also can not assume any in any such matters
- ◎ If it was the case or mounting that has been processed like a product, it will not be covered under warranty.
- $\odot$  It is not possible to inquire of the combination of other manufacturers.
- ◎ Product may have edges or protrusions. Be sure to wear working gloves.
- (Please wear work gloves when working, even if a photo in this article show without work gloves.)
- O It is a general-purpose filter tailored to carburetor. Some vehicle by interfering with frame or the like, might not be installed. If you are installing in own models, check the size etc always.
- © Conduct inspections every 1000Km, replace filter if you have clogged. If you continue to use, please note that it leads to performance loss.
- ⊚ Our 03-05-0442: MIKUNI VM26 carburetor kit for air filter and frame is interference, please note that can not be installed


### When the handling of ignoring this display, property damage and human shows the assumption of what injury.

- When performing the work,etc.,be sure during the cold (when the engine and the muffler is cold). (It may cause burns.)
- When performing the work, it should be made to prepare the tools for the job. (Breakage of parts, it may cause injury.) ■ The product and the frame, might have edges or protrusions. When working, please wear work gloves to protect your hands. (It may cause injury.)
- Be sure to each part inspection before operation, check the loosening of the threaded portion, be sure to securely tighten the specified torque if there is loose. (It may cause detachment of the parts.)
- It can not rain running of mounting this filter. Please note that cause of engine malfunctions.

### ⚠ Warning When the handling of ignoring this display people died, shows the contents of the serious injury possibility is assumed.

- When performing the work, etc., be sure during the cold (when the engine and the muffler is cold). (It may cause burns.)
- During operation, when an abnormality occurs, immediately stop the vehicle in a safe place, please stop running. (It may lead to an accident.)
- When performing the work, do the work safely stabilize the vehicle in a horizontal location.
- (There is a risk of injury vehicle collapsed while working.)
- Inspection, maintenance, the instruction manual or, inspection methods such as service manuals, to protect the way, should be done correctly. (unsuitable inspection and maintenance, there is a risk that result to an accident.)
- When carrying out the inspection and maintenance etc., if found damaged parts replace the damaged parts to avoid possible to reuse the parts. (There is a risk that lead to accidents Continued use.)
- © Please note. Performance up, the design change, the product and the price in the cost up, etc. are subject to change without notice.
- © For claims, only to products that have been recognized to be defective in material and processing to the extent within one month after purchase, we will repair or replace. However all of the cost of such exchange fees are not eligible.
- Correct installation and, if it is not protected, such as how to use, it does not have this limitation.
- O Until it is destroying the product, please keep this manual.

## Product content



No	٥.	Product content	Quantity
	1	Air filter COMP.	1
	2	Clamp	1

O In a state of loosened clamp, fit connecting tube to suction port of carburetor. Tighten the clamp, then fixed.



CONTACT Address: 3-5-16 Nishikiorihigashi Tondabayashi Osaka JAPAN TEL: +81-721-25-1357 FAX:+81-721-24-5059 e-mail:english@takegawa.co.jp URL http://www.takegawa.co.jp Please contact with your name and country name provided. (Only English please)

